



Type F
(fixed)




Type TO
(tilt only)



Type TT
(tilt & turn)



Type B
(bi-folding)



Type S
(sliding)




Type O
(outward)




Type HD
(hinged)




Type FD
(french)



Type BD
(bi-folding)



Type SD
(sliding)



Type ED
(entrance)



NOTES:

- Triangle with dashed lines means that the element is outward opening
- The open end of the triangle is the hinge side of the window or door sash (for all, inward, outward and tilt opening elements)
- All drawings are viewed from inside!
- Overview shows common types only. There are by far more configurations available, for example combining 2 or 3 types together, adding transoms/mullions, creating "bay windows" by joining different types with 45° or 90° corner posts, changing size relations of opening and fixed panes, adding Colonial/Georgian bars, etc.
- As long as the sizes remain the same, price does not change if opening sash moves from left hand side to right hand side (e.g type TT-5), from top to bottom or from left hinged / slide / fold direction to right hinged / slide / fold.